





## HZ 90-400

| TYP/TYPE       | HZ 90-400/1350 | HZ 90-400/1800 | HZ 90-400/2400 |
|----------------|----------------|----------------|----------------|
| A              | 1350           | 1800           | 2400           |
| B              | 1710           | 2160           | 2760           |
| C              | 2210           | 2660           | 3260           |
| D              | 1330           | 1780           | 2380           |
| E              | 1570           | 2020           | 2620           |
| F              | 2800           | 3200           | 3400           |
| G              | 1855           | 2080           | 2380           |
| H              | 1155           | 1380           | 1680           |
| I              | 315            | 367            | 419            |
| K              | 3090           | 3547           | 3999           |
| L              | 2340           | 2530           | 2840           |
| $M_{min}$ (kW) | 355            | 400            | 450            |
| $M_{max}$ (kW) | 500            | 600            | 800            |
| N              | 2280           | 2650           | 3180           |
| O              | 1295           | 1520           | 1820           |
| P              | 3150           | 3600           | 4200           |
| Q              | 4945           | 5627           | 6379           |
| R              | 2200           | 2400           | 2400           |
| S              | 3000 ÷ 15000   | 3000 ÷ 15000   | 3000 ÷ 15000   |